RABBIT

OVERVIEW

All products by The Rabbit Company $^{\text{TM}}$ are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.

The Thrusting Rotating Warming Rabbit



External Stimulator

Power Button & Rotating and Thrusting Button - Head

Vibration Function Button & Warming Function Button - Rabbit Shaft

Pin Charging Port (back of device)



GETTING STARTED

 Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (Not included).



- Pulsating light Flashing = Charging
- · Solid Light = Fully Charged
- Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.
- 3. Lubricate your rabbit (if needed) with a water based, silicone compatible lubricant.



FAQs can be found at www.TheRabbitCompany.com Email us at customercare@TheRabbitCompany.com for any unanswered questions

- 4. Press and hold the \circlearrowleft button for 3 seconds to turn your Rabbit ON/OFF.
- 5. To turn ON the rotating and thrusting functions at the same time, and/or cycle through speeds, press the σ button. Press and hold to turn OFF.
- 6. To turn ON the vibrations on the shaft and/or cycle through speeds, press the M button. Press and hold the O button to turn OFF. Press and hold the M button 3 seconds to turn on/off the warming function.
- 7. The Rabbit has pulsating light at the bottom of the device.



CONTROLLING YOUR RABBIT

- $\, \cdot \,$ Press and hold the \mho button for 3 seconds to turn your Rabbit ON/OFF.
- Press the O button to turn on and increase rotating and thrusting functions at the same time. The rainbow pulsating light at the bottom will turn on. There are a total of 9 rotating and thrusting modes. Press and hold the O button for 3 seconds to turn OFF.
- Press the W button to turn on and increase vibration intensity on the shaft. The rainbow pulsating light at the bottom will turn on. There are a total of 9 vibration modes. Press and hold the O button for 3 seconds to turn OFF.
- Press and hold the W button 3 seconds to turn on/off the warming funciton on the head (Heating 40±2°C). The red indicator on the bottons will on/off to show the warming function.



CHARGING

- Insert the pin charging plug into the designated charging area
- The pulsating light indicates item is charging
- Solid light indicates item is fully charged
- Rabbits require approximately 2 hours for full charge



FUNCTIONS



Head Stimulator 9 Rotating and Thrusting Modes and Warming function



Before rotating, can bend the Rabbit body above on wrinkled areas a little to tune the rotating range



Rabbit Stimulator 9 Vibrating Modes

HARE CARE™

Cleaning, Storage & Safety

- Always clean your Rabbit thoroughly before and after each use.
- We recommend using a premium water-based lubricant when needed.
 Silicone-based lubricants are not recommended and can cause damage to the Rabbit. Never use hand cream, or massage oils as lubricants for your intimate areas.
- 3. To properly clean your Rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean and pat dry using a





lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

- 4. Avoid leaving your Rabbit in direct sunlight and never expose it to extreme heat.
- 5. Our products is waterproof. After use in the bath/ shower, please make sure to completely and thoroughly dry before storage. For best product performance, limit bathtub use to 15 minutes and no longer than 30 minutes.



If your Rabbit appears to function abnormally, turn OFF and consult our customer care section on TheRabbitCompany.com where you will find help tips. Should you require further assistance please contact: customercare@TheRabbitCompany.com

SPECIFICATIONS

Materials Charging Body Safe Silicone / ABS 2 hours

Size Use Time

222 x 94 x 46 mm 1 hour

Weight Max Noise Level

268.5 g <68 db

Battery Li-ion 800 mAh Head: 9 Thrusting and

Rotating modes Warming function **IPX** Rabbit: 9 Vibrations modes

Interface

IPX7 Waterproof

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

CE UK RoHS X

F



Complete user instructions in additional languages can be found at:

www.TheRabbitCompany.com

Designed and Developed by The Rabbit Company™

Made in China © The Rabbit Company™

FAQs can be found at www.TheRabbitCompany.com Email us at customercare@TheRabbitCompany.com for any unanswered questions

