


bodywand® gplay

USER GUIDE



HOW TO USE

• COME HITHER LICKING MODE

Hold the  button for 3 seconds to turn the device on or off.

There are 10 adjustable licking modes. Press the  button to cycle through each mode. Hold the  button to stop.

• CLITORAL STIMULATOR VIBRATION MODE

There are 10 adjustable vibration modes. Press the  button to cycle through each mode. Hold the  button to stop. Both modes run simultaneously.

• TRAVEL LOCK

This device features a travel lock function. Press and hold the  and  for 3 seconds to lock/unlock. The LED will flash to confirm travel mode.

• CHARGING THE DEVICE

Attach the included cable to the two magnetic charging nodes. The device will not function while charging, unplug the charger before using the device.

Flashing LED Light: Item is charging.
Solid LED Light: Item is fully charged. It takes approx 150 minutes of charge for up to 60 minutes of use.

CLEANING, STORAGE & SAFETY

Always clean and dry your device thoroughly before and after use.

DO NOT store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items. Clean the device with a soft, damp cloth.

DO NOT clean with an alcohol or chemical-based cleaner.

Use water based lubricant as desired.

Not compatible with silicone lubricant.

Avoid leaving your device in direct sunlight and never expose it to extreme heat.

Keep away from water, and never immerse it.

WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

SPECIFICATIONS

BW808

Size:

Tamaño: 5cm x 4cm x 21cm
Taille:
Größe:

Weight:

Peso: 180g
Poids:
Gewicht:

Material:

Material: ABS + Silicone
Matériau: ABS + Silicone
Material: ABS + Silicone

Battery:

Bateria: 700mAh
Batterie:
Akku:

SPECIFICATIONS

Power:

3.7V 700mAh USB2.0

Splashproof:

IPX6 Splashproof, for cleaning the device.
Not to be used under water.

Battery Life:

Charging time: 150 minutes for up to 60 minutes of use.

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC

Horsham, PA 19044 All Rights Reserved

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.
Phone: +44 2037692960,
E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:


ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.
Phone: +34 910054258,
E-Mail: EUresponsibleperson@arangaranga.com

Email us at sales@xgenproducts.com for any unanswered questions

www.thebodywand.com

bodywand® gplay

USER GUIDE



HOW TO USE

• CLITORAL STIMULATOR VIBRATION MODE

Hold the  button to turn on the vibration mode. There are 10 adjustable modes. Press the  button to cycle through each mode. Hold the  button to stop.

• WAVE TAPPING MODE

Hold the  button to turn on the vibration mode. There are 10 adjustable modes. Press the  button to cycle through each mode. Hold the  button to stop.

• G-SPOT VIBRATION MODE

Hold the  button to turn on the vibration mode. There are 10 adjustable modes. Press the  button to cycle through each mode. Hold the  button to stop.

• TRAVEL LOCK

This device features a travel lock function. Press and hold the  and  for 3 seconds to lock. The device will vibrate one time to confirm travel mode.

• CHARGING THE DEVICE

Attach the included cable to the two magnetic charging nodes. The device will not function while charging, unplug the charger before using the device.

Flashing LED Light: Item is charging
Solid LED Light: Item is fully charged
It takes approx 150 minutes of charge for up to 60 minutes of use.

CLEANING, STORAGE & SAFETY

Always clean and dry your device thoroughly before and after use.

DO NOT store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items. Clean the device with a soft, damp cloth.

DO NOT clean with an alcohol or chemical-based cleaner.

Use water based lubricant as desired.

Not compatible with silicone lubricant.

Avoid leaving your device in direct sunlight and never expose it to extreme heat.

Keep away from water, and never immerse it.

WARNING

For adult use only. For external use only.

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

SPECIFICATIONS

BW809

Size:

Tamaño: 23.2cm x 3.7cm x 3.5cm

Taille:

Größe:

Weight:

Peso: 202g

Poids:

Gewicht:

Material:

Material: ABS + Silicone

Matériau: ABS + Silicone

Material: ABS + Silicone

Material: ABS + Silikon

Battery:

Bateria: 1200mAh

Batterie:

Akku:

SPECIFICATIONS

Power:

3.7V 1200mAh USB2.0

Splashproof:

IPX6 Splashproof, for cleaning the device.

Not to be used under water.

Battery Life:

Charging time: 150 minutes for up to 60 minutes of use.

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC

Horsham, PA 19044 All Rights Reserved

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.

Phone: +44 2037692960,

E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:

ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.

Phone: +34 910054258,

E-Mail: EUresponsibleperson@arangaranga.com

Email us at sales@xgenproducts.com for any unanswered questions

www.thebodywand.com