

THE
RABBIT
COMPANY™

OVERVIEW

All products by The Rabbit Company™ are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that cannot be matched and will have you craving for more.

THE MINI THRUSTING RABBIT™



External Stimulators

Power/ Vibration Function Button

Thrusting Function Button

Magnetic Charging Port (back of device)




GETTING STARTED

1. Before first use, charge your Rabbit for approximately 1.5 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (Not included).

- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed

2. Wash your Rabbit with soap and water, or toy cleaner suitable for use with silicone items.




3. Lubricate your Rabbit (if needed) with a water based, silicone compatible lubricant.

4. Press and hold the  button for 3 seconds to turn vibration mode ON/OFF.

5. To cycle through vibration patterns, press the  button.

6. Press and hold the  button for 3 seconds to turn thrusting mode ON/OFF.

7. To cycle through thrusting patterns, press the  button



CONTROLLING YOUR RABBIT

- Press and hold the  button for 3 seconds to turn vibration mode ON/OFF.
- To cycle through vibration patterns, press the  button, There are a total of 7 vibration modes.
- Press the  button for 3 seconds to turn thrusting mode ON/OFF.
- To cycle through thrusting patterns, press the  button, There are a total of 3 thrusting modes.




CHARGING

- Attach the magnetic charging plug to the designated charging area on the back of device.



- Flashing light indicates item is charging

Flashing Light = Charging




- Solid light indicates item is fully charged




Solid Light = Fully Charged

VIBRATION PATTERNS



THRUSTING MODES



1. Always clean your Rabbit thoroughly before and after each use.

2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the Rabbit. Never use hand cream, or massage oils as lubricants for your intimate areas.

3. To properly clean your Rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean



and pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

4. Avoid leaving your Rabbit in direct sunlight and never expose it to extreme heat.



5. The mini rabbit is waterproof. After use in the bath/ shower, please make sure to completely and thoroughly dry before storage. For best product performance, limit bathtub use to 15 minutes and no longer than 30 minutes.



SPECIFICATIONS

Materials

Body Safe ABS / Silicone

Size

174x33x64 mm

Weight

155 g

Battery

Li-ion 500 mAh

Charging

1.5 hours

Use Time

1 hour

Max Noise Level

<68 db

Interface

7 vibration modes

3 thrusting modes

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.



RoHS



FR

**Cet appareil, ses accessoires
et cordons se recyclent**

**À DÉPOSER
EN MAGASIN**



**À DÉPOSER
EN DÉCHÈTERIE**

OU



Points de collecte sur www.quefairedemesdechets.fr

Complete user instructions in
additional languages can be
found at:

www.TheRabbitCompany.com

Designed and Developed by
The Rabbit Company™

Made in China
© The Rabbit Company™

TheRabbitCompany.com