

THE
RABBIT
COMPANY™

OVERVIEW

All products by **The Rabbit Company™** are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that cannot be matched and will have you craving for more.

The 3 Way Rabbit TM




External Stimulators

Power Button / Clitoral Stimulator Button

Suction Function Button

Vibration Function Button - Head

Magnetic Charging Port
(back of device)





GETTING STARTED

1. Before first use, charge your Rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB / AC power adapter (not included).

- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed

2. Wash your Rabbit with soap and water, or toy cleaner suitable for use with silicone items.



FAQs can be found at
www.TheRabbitCompany.com

Email us at
customercare@TheRabbitCompany.com
for any unanswered questions

3. Lubricate your Rabbit (if needed) with a water based, silicone compatible lubricant.


4. Press and hold the  button for 3 seconds to turn your Rabbit ON.

5. To turn ON the vibrations in the head, and/or cycle through speeds, press the  button. Press and hold to turn OFF.

6. To turn ON the clitoral lick and/or cycle through speeds, press the  button. Press and hold to turn OFF.

7. To turn ON the suction and/or cycle through intensities, press the  button. Press and hold to turn OFF.

8. Press and hold the  button for 3 seconds to turn your device OFF.



CONTROLLING YOUR RABBIT

- Press and hold the  button for 3 seconds to turn your Rabbit ON.
- Press the  button to turn on and increase vibration intensity in the head. There are a total of **9** vibration modes. Press and hold to turn OFF
- Press the  button to turn on suction and cycle through intensity levels. There are a total of **4** suction intensities. Press and hold to turn OFF
- Press the  button to turn on and increase the clitoral licker intensity. There are a total of **9** licking modes. Press and hold to turn OFF
- Press and hold the  button for 3 seconds to turn your device OFF.




CHARGING

- Attach the magnetic charging plug to the designated charging area on the back of device.

- Flashing light indicates item is charging

- Solid light indicates item is fully charged

- Rabbits require approximately **2** hours for full charge



Flashing light = Charging





Solid light = Fully Charged



HOW TO USE THE SUCTION CAP

- Rotate the suction cap anticlockwise to unlock and remove.
- Insert suction cap as shown and rotate clockwise to lock.



HARE CARE™

Cleaning, Storage & Safety


1. Always clean your Rabbit thoroughly before and after each use.
2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the Rabbit. Never use hand cream, or massage oils as lubricants for your intimate areas.



HARE CARE™

Cleaning, Storage & Safety

3. To properly clean your Rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your Rabbit with luke-warm water and an antibacterial soap. Rinse clean and pat dry using a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.





HARE CARE™

Cleaning, Storage & Safety

4. Avoid leaving your Rabbit in direct sunlight and never expose it to extreme heat.
5. Our products are designed to be splash-proof. Never immerse your Rabbit in water.

If your Rabbit appears to function abnormally, turn OFF and consult our customer care section on **TheRabbitCompany.com** where you will find help tips. Should you require further assistance please contact: **customercare@TheRabbitCompany.com**



SPECIFICATIONS

Materials

Body Safe ABS / Silicone

Size

269.7x64.3x36.2 mm

Weight

234 g

Battery

Li-ion 420 mAh

Charging

2 hours

Use Time

1 hour

Max Noise Level

<68 db

Interface

9 licking patterns

4 suction intensities

9 vibration patterns

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.



RoHS



FR

Cet appareil,
ses accessoires
et cordons se
recyclent

À DÉPOSER
EN MAGASIN



OU

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr

Complete user instructions in
additional languages can be
found at:

www.TheRabbitCompany.com

Designed and Developed by
The Rabbit Company™

Made in China
© The Rabbit Company™

FAQs can be found at
www.TheRabbitCompany.com

Email us at
customercare@TheRabbitCompany.com
for any unanswered questions

TheRabbitCompany.com